

CELERO 5G SC[™]



User Manual

Table of Contents

Important Health and Safety Information	3
Get Started	9
Phone Layout and Functions	9
Setup	10
Install the SIM/SD Card	10
Charge the Battery	11
Power Your Phone On	11
Power Your Phone Off	11
Basic Operations	12
Lock and Unlock Your Screen	12
Home Screen	12
Wallpaper	15
Connectivity	16
USB	16
Wi-Fi	16
Tethering & Mobile Hotspot	16
Bluetooth	17
Phone, Contact & Message	18
Make and Answer Calls	18
Call Settings	18
Contacts	19
Add a Contact	19
Edit a Contact	19
Delete a Contact	19
Share a Contact	19
Messages	19
Send a Text Message	19
Send a Multimedia Message (MMS)	20
Messenger Settings	20
Apps and Entertainment	21
BoostMax Audio	21
Camera	22
Switch Camera Modes	23
Take a Photo	23
Record a Video	23
Photo	23
Calendar	24
Add an Event to the Calendar	24
Edit an event	24
Delete an event	24
Clock	24
Set the Date and Time	24
Set Alarms	25

Useful Settings	26
Sound & Vibration	26
Display	26
Accessibility	26
Security & Privacy	27
Safety & Emergency	28
Digital Well-being & Parental Controls	28
Language	28
Keyboard	28
Date & Time	29
Update Your Phone	29
About Phone	29
Appendix	30
Troubleshooting	30
FCC Notice and Cautions	31
Consumer Information on SAR	32
FCC Hearing-Aid Compatibility (HAC) Regulations for Wireless Devices	34
Celero5G SC Limited Warranty	35
Warranty Contact Information	38
Copyright Information	38

Important Health and Safety Information

When using this product, the safety precautions below must be taken to avoid possible legal liabilities and damages. Retain and follow all product safety and operating instructions. Observe all warnings in the product operating instructions. To reduce the risk of bodily injury, electric shock, fire, and damage to the equipment, closely observe all of the following precautions.

Safety Precautions for Proper Grounding Installation

Caution: Connecting to improperly grounded equipment can result in an electric shock to either you or your device. This product is equipped with a USB Cable for connecting to a desktop or notebook computer. Be sure your computer is properly grounded before connecting this product to the computer. The power supply cord of a desktop or notebook computer has an equipment-grounding conductor and a grounding plug. The grounding plug must be plugged into an appropriate outlet which is properly installed and grounded in accordance with all local codes and ordinances.

Safety Precautions for Power Supply Unit

Use the correct external power source. A product should be operated only from the type of power source indicated on the electrical rating label. If you are not sure of the type of power source required, consult your authorized service provider or local power company. For a product that operates from battery power or other sources, refer to the operating instructions that are included with the product.

Electrical Safety

This product is intended for use when supplied with power from the designated battery or power supply unit. Other usage may be dangerous and will invalidate any approval given to this product. Handle battery packs carefully. This product contains a Li-ion battery. There is a risk of fire and burns if the battery pack is handled improperly. Do not attempt to open or service the battery pack. Do not disassemble, crush, puncture, short external contacts or circuits, dispose of in fire or water, or expose a battery pack to temperatures higher than 55°C (131°F).

Note: Danger of explosion if battery is incorrectly replaced. Replace only with specified batteries. To replace the battery, take the device to an authorized service center. Recycle or dispose of used batteries according to all applicable local regulations, or in accordance with the instructions in the reference guide.

Follow these other specific precautions:

- Keep the battery or device dry and away from water or any liquid as it may cause a short circuit.
- The phone should be connected only to products that bear the USB-IF logo or have completed the USB-IF compliance program.
- Keep metal objects away so they do not come in contact with the battery or its connectors as it may lead to short circuits during operation.
- Always keep the battery out of the reach of babies and small children to avoid swallowing. Consult a doctor immediately if the battery is swallowed.
- Do not use a battery that appears damaged, deformed, discolored, has any rust on its casing, if it overheats, and/or if it emits a foul odor.

- Use of an unqualified battery or charger may present a risk of fire, explosion, leakage or other hazard.
- Only use the battery with a charging system that has been qualified with the system per this standard: IEEE-Std-1725-2011.
- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface causing damage, take it to a service center for inspection.
- If the battery leaks: Do not allow the leaking fluid to come in contact with your eyes. If contact occurs, DO NOT rub your eyes. Rinse with clean water immediately and seek medical advice. Do not allow the leaking fluid to come in contact with skin or clothing. If contact occurs, flush the affected area immediately with clean water and seek medical advice. Take other precautions to keep a leaking battery away from fire as there is a danger of ignition or explosion.

Prevention of Hearing Loss

Caution: Permanent hearing loss may occur if earphones or headphones are used at high-volume levels for prolonged periods of time.

Safety Precautions for Direct Sunlight

Store this product away from excessive moisture and extreme temperatures. Do not leave the product or its battery inside a vehicle or in places where the temperature may exceed 55°C (131°F), such as on a car dashboard, window sill, or behind glass that is exposed to direct sunlight or strong ultraviolet light for extended periods of time. This may damage the product, overheat the battery, or pose a risk to the vehicle.

Environmental Restrictions

Do not use this product in gas stations, fuel depots, chemical plants or where blasting operations are in progress, or in potentially explosive atmospheres such as fueling areas, fuel storehouses, below deck on boats, chemical plants, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powders. Please be aware that sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Aircraft Safety

Due to the possible interference caused by this product to an aircraft's navigation system and its communications network, using this device's phone function on board an airplane is prohibited in most countries. If flight personnel authorize use of electronic devices, switch your device to Airplane Mode (Please see page 29 of this User Guide for instructions) to turn off RF functions that may cause interference.

Road Safety

In many jurisdictions, vehicle operators are not permitted to use communication services with handheld devices while the vehicle is in motion, except in the case of emergency. In some countries, using hands-free devices as an alternative is allowed.

Safety Precautions for RF Exposure

- Use of non-original, non-manufacturer-approved accessories may violate your local RF exposure guidelines and should be avoided.
- Use only original, manufacturer-approved accessories when such accessories contain metal of any kind.

- Avoid using your phone near strong electromagnetic sources, such as microwave ovens, sound speakers, TV, and radio.
- Avoid using your phone near metal structures (for example, the steel frame of a building).

Explosive Atmospheres

When in an area with a potentially explosive atmosphere or where flammable materials exist, the device should be turned off and the user should obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Users are advised not to use the equipment at refueling points such as service or gas stations and are reminded of the need to observe restrictions on the use of radio equipment in fuel depots, chemical plants, or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked such as fueling areas, below deck on boats, fuel or chemical transfer or storage facilities, and including, but not limited to areas where the air contains chemicals or particles such as grain, dust, or metal powders.

Interference with Medical Equipment Functions

This product may cause medical equipment to malfunction. The use of this device is prohibited in most hospitals and medical clinics for which regulations and rules are commonly posted in such facilities. In these instances, turn your phone OFF as healthcare facilities frequently use equipment that is adversely affected by RF energy. If you use any personal medical device(s), consult the manufacturer of your device(s) to determine if the device(s) is adequately shielded from external RF energy. Your healthcare provider may be able to assist you in obtaining this information.

Non-ionizing Radiation

Your device has an internal antenna. This product should be operated in its normal-use position to ensure the radiative performance and safety from interference. As with other mobile radio transmitting equipment, users are advised that for satisfactory operation of the equipment and for personal safety, it is recommended that no part of the human body should come too close to the antenna during equipment operation.

Use only the supplied integral antenna. Use of unauthorized or modified antennas may impair call quality and damage the phone, causing loss of performance and SAR levels exceeding the recommended limits, as well as causing non-compliance with local and national regulatory requirements.

In order to limit RF energy exposure and to ensure optimal phone performance, operate the device only in its normal-use position. Contact with the antenna area may impair call quality and cause your device to operate at a higher power level than needed which can reduce antenna performance and battery life.

Battery Information and Precautions

To assure product safety, please follow the precautions listed below:

Danger!

- Use dedicated chargers and follow the specified conditions when charging the cell.
- Use the cell only with the specified equipment.
- Do not open the back cover and replace or fix the battery yourself.

- Do not put or store the cell together with metal articles such as necklaces, hairpins, coins, or screws.
- Do not short circuit the (+) and (-) terminals with metal conductors.
- Do not place the cell in a device with the (+) and (-) in a reverse way.
- Do not penetrate the cell with a sharp article such as a needle.
- Do not disassemble the cell.
- Do not weld the cell directly.
- Do not use a seriously damaged or deformed cell.
- Thoroughly read the user's manual before use. Inaccurate handling of lithium-ion cells may result in heat, fire, explosion, damage, or the capacity loss of the cell.

Warning!

- Do not put the cell into a heating vessel, washing machine or high-pressure container.
- Do not use the cell with batteries of a different package, type, or brand.
- Stop charging the cell if charging is not completed within the specified time.
- Stop using the cell if abnormal heat, odor, discoloration, deformation, or abnormal condition is detected during use, charge, or storage.
- Keep away from the cell immediately when leakage or foul odor is detected.
- Wash well with clean water immediately if liquid leaks onto your skin or clothes.
- If liquid leaking from the cell gets into your eyes, do not rub your eyes.
- Wash them well with clean water and call a physician immediately.

Caution!

- Store batteries out of reach of children so that they are not accidentally swallowed or handled.
- If younger children use the cell, parents or guardians should explain proper handling of the device.
- Be sure to read the user's manual thoroughly before using the cell.
- Batteries have a life cycle. Replace a failed cell with a new cell that is the same brand immediately after normal life cycle expiration, or if expiration has occurred prematurely.
- Store the battery in a low-humidity and low-temperature environment if the battery won't be used for an extended period of time.
- Keep the cell far away from articles or materials with static electric charges while the cell is charged, used, or stored.
- Wipe with a dry cloth before using the cell if the terminals of the cell become dirty.

Safety Instructions for Wall Charger

Please read the following information carefully:

- The maximum ambient temperature for use of the wall charger shall not exceed 45°C (113 °F).
- The wall charger shall be installed according to specification. The current of load and output power shall not exceed the following values:
 - Input: AC100-240V @ 50/60Hz; 0.35A
 - Output: DC5V; 2A
- The wall charger shall be used for IT equipment only.
- The wall charger is designed for indoor use only.
- Cleaning – Unplug the wall charger from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners to clean: use only a dry cloth.
- Water and moisture – Do not use this product in a moist or wet environment.
- Self-servicing – Attempting to service this product on your own, or opening or removing device covers may result in exposure to dangerous voltage or other hazards.
- Unplug the wall charger during lightning storms or when unused for lengthy durations.
- This wall charger is not intended to be repaired by service personnel in case of failure or component defect.

Get Started

Here's all the information you'll need to set up your phone for the first time.

Phone Layout and Functions

Note: Your phone's screen and app layouts are subject to change. This user guide uses sample images only.

The following illustration outlines your phone's primary external features and keys.




Components	Description
Speaker	Allows you to hear the caller and automated prompts.
Front camera	Allows you to take photos, record videos, or join video conferences while facing the screen.
Volume key	Allows you to adjust the media volume, ringtone volume or voice volume.
Power key	Allows you to turn the phone, or the screen, on or off.
Rear camera	Allows you to take photos and videos.
Bottom speaker	Allows you to hear different ringtones, sounds or the caller's voice in speakerphone mode.
USB Type-C	Allows you to connect the phone charger or the USB cable.
Headset connector	Allows you to plug in either a stereo headset or an optional headset for convenient, hands-free conversations.
Microphone	Transmits your voice for phone calls or records your voice or ambient sounds for voice recordings and videos.
Flash	Helps illuminate subjects in low-light environments when the camera is focusing and capturing a photo or video.
SIM and microSD™ tray	Follow the steps below to install the SIM and microSD cards.

CAUTION: Inserting an accessory into the incorrect jack may damage the phone.

Setup

Install the SIM/SD Card

Please follow the steps below to install the SIM card into your phone. Please note that you don't have to insert a SIM card to make an emergency call (9-1-1). Use only nano-SIM cards with this device. Do not attempt to insert any other types of SIM cards to avoid damaging your device.




1. Insert the provided SIM pin to eject the SIM tray and then slide it out gently.
2. Place or remove the nano-SIM card and the microSD™ card in the correct slot as shown above.

NOTE: A SIM pin is included in the box. microSD™ memory cards are sold separately.

Charge the Battery

1. Insert the USB-C cable into the phone and the charger head.
2. Plug the charger head to the power outlet.



Power Your Phone On

Press and hold the Power key on the middle-right edge of your phone to turn on your phone.

NOTE: The first time you turn the phone on, you'll see the startup screens. Follow the instructions on each screen to set up your phone.

Power Your Phone Off

1. Press and hold the Power key and the Upper Volume Key until the menu pops up.
2. Tap **Power off**.

Basic Operations

The following topics offer an overview of your phone's basic operations.

Lock and Unlock Your Screen


Your phone allows you to quickly turn the screen off when not in use, turn the screen back on, and unlock your phone.

Turn the Screen On and Unlock It

1. To turn the screen on, press the Power key.
2. Swipe your finger across the screen to unlock it.




Note: If you've set up a screen lock, you'll be prompted to draw the pattern or enter the password or PIN. See [Screen Lock](#).

Home Screen



Home Screen Layout





Your Home Screen extends beyond the initial screen. Swipe the screen left to display additional screens.





Item	Description
Status bar	The status bar displays icons to notify you of your phone's service status (on the right side) and notifications (on the left side).
Notification area	The notification area of the status bar (on the left) displays notifications for incoming messages, missed calls, application updates, and more. Pull down the status bar to display the notification panel.
Status area	The status area of the status bar (on the right) displays phone and service status information such as signal strength, battery status, Wi-Fi and data connectivity, and ringer status.
Apps	Application icons are shortcuts to your favorite applications. You can add and remove these shortcuts as you wish.
Widget	Press and hold any blank space on the Home Screen, and select Widget to add your favorite widgets on the Home Screen.
Recent apps button 	Tap to display a list of recently used applications.
Home button 	Tap to display the Home Screen from any other screen.
Back button 	Tap to return to the previous screen.

Status Bar

The Status Bar at the top of the Home Screen provides **Notification** alerts on the left side and **Phone and Service Status** information on the right side. To view the notification panel or access the Quick Settings panel, pull down the status bar from the top of the screen.













Main Notification Icons

Icon	Notification
	Missed call
	New voicemail
	Downloading
	New Gmail

	New text or MMS message
	Wi-Fi available
	Alarm
	Warnings

NOTE: Additional notification icons may appear. All notifications may be accessed through the Notification panel. Pull down the status bar from the top of the screen to display the Notification panel.

Main Status Icons

Icon	Status
	Bluetooth® active
	Wi-Fi® active
	Network (full signal)
	Network (roaming)
	4G LTE
	5G
	Hotspot on
	Airplane mode
	Sync active
	Alarm set
	Battery (charging)
	Battery (full charge)

Quick Settings Panel

You can access the Quick Settings panel by pulling down the status bar. From there, you can check notifications, use the Quick Settings menu, and more.

Open the Quick Settings Panel

- Pull down the status bar. (Slide your finger down from the top of the screen.)

Close the Quick Settings Panel

- Tap **Home**  or **Back**  to close the Quick Settings panel.

Notifications Panel

Notifications remind you of new messages, calendar events, and alarms. Swipe down from the top of your phone screen to open the Notifications panel and view details. Swipe the Notifications panel down to hide. If the Notifications panel is hidden, swipe up from the Quick Settings panel to display it again.

Wallpaper

Change the Wallpaper

Select and assign your phone's background wallpaper.

1. From the Home Screen, tap and hold an empty space to display the Home Screen menu, and then tap **Wallpaper & style**.

You can also access the wallpaper menu through settings. From the Home Screen, swipe up and tap

Settings  > **Wallpaper & style**.

2. Select from **Photos** or **Wallpapers**
3. Select a wallpaper to preview.
4. Tap an option to select the wallpaper.
 - **Home Screen:** Set the background wallpaper for your Home Screen.
 - **Lock Screen:** Set the wallpaper for your phone's lock screen.
 - **Home and Lock Screen:** Set a wallpaper for both your Home Screen and your lock screen.

Connectivity


The following topics address your phone's connectivity options, including USB, Wi-Fi, Tethering/Mobile Hotspot, and Bluetooth.

USB

You can use the supplied USB cable to connect your phone directly to your computer and transfer music, photos, and other content files.


1. Connect your phone to your computer using the supplied USB/charging cable.
2. Pull down the status bar to display the notifications panel. Tap **Charging this device via USB**, you'll see either **Use USB for File Transfer, USB tethering, MIDI, PTP** or **No data transfer**.
3. On your computer, navigate to the detected device (such as through the My Computer menu) and open it.
4. If available, select a drive (SD card or internal shared storage).
5. Select a folder (for example, **Music** for songs and albums) and copy files to it from your computer.
6. When you're done, disconnect (eject) your phone from your computer.

Wi-Fi

1. From the Home Screen, swipe up and tap **Settings**  .
2. Tap **Network & internet > Internet > Wi-Fi**.
3. Tap the Wi-Fi slider to turn Wi-Fi on. To disable Wi-Fi, tap the slider again.
4. Tap a Wi-Fi network to connect, enter the password (if it's not an open network), and then tap **Connect**.

Tethering & Mobile Hotspot


Tethering

1. From the Home Screen, swipe up and tap **Settings**  .
2. Tap **Network & internet > Hotspot & tethering**.
3. Configure hotspot and tethering with the on-screen options.
4. Tap the corresponding slider to turn on hotspot or tethering.


Connect to Hotspot

1. Enable Wi-Fi functionality on your target device (laptop, media device, etc.).
2. Scan for Wi-Fi networks on the target device and select your phone hotspot from the list of available Wi-Fi networks.
3. After selecting the phone hotspot, follow the onscreen instructions to enter the password. Tap on Wi-Fi Hotspot on your phone to reveal the password onscreen instructions to enter the password (provided on the hotspot page).


Bluetooth

1. From the Home Screen, swipe up and tap **Settings** .
2. Tap **Connected devices > Connection preferences > Bluetooth**.
3. Tap the slider to turn Bluetooth on.

Pair Bluetooth Devices


1. Enable the Bluetooth function on the Bluetooth devices being paired beforehand.
2. From the Home Screen, swipe up and tap **Settings** .
3. Tap **Connected devices > Connection preferences > Bluetooth**.
4. Tap **Pair new device**.
5. Tap a device from the “Available devices” list and follow the onscreen instructions to pair with the device.

Forget a Paired Device

1. From the “Connected devices” menu, tap **Settings** , next to the paired device you wish to forget (unpair).
2. Tap **FORGET**.

Send Information Using Bluetooth

You can use Bluetooth to transfer information between your phone and another Bluetooth-enabled device such as a phone or laptop computer.

1. Pair your phone with another device by following the **Pair Bluetooth Devices** steps above.
2. Select the file you want to transfer, like a contact, for example.
3. From the Home Screen, swipe up and tap **Contacts**.
4. Tap a contact to send.
5. Tap **Menu**  **> Share > Bluetooth**.
6. Tap a paired device to receive the data.




Phone, Contact & Message

The following topics outline the use of your phone app, messages app, and more.

Make and Answer Calls

Make a Call


The most common way to place a call is by using the phone's keypad screen.

1. From the Home Screen, tap **Phone**  to display the phone screen.
2. Tap the number keys on the keypad to enter the phone number.
3. Tap  to call the number.
4. To end the call, tap .

Call Emergency Numbers


If your phone has network coverage, dial the emergency number and tap to make an emergency call. This works even without a SIM card and without typing the PIN code. Although all devices are equipped with 9-1-1 emergency calling, service limitations can impact whether your device's location information will be successfully transmitted during a 9-1-1 call.*

To call the 9-1-1 emergency number when the phone's screen is locked with a screen lock:

1. From the lock screen, swipe up and tap **Emergency**.
2. Tap 911 and tap .

NOTE: As long as you are in an area covered by wireless service, the emergency call is placed.

To call the 9-1-1 emergency number normally or when your account is restricted:



1. Unlock the screen.
2. From the Home Screen, tap **Phone** > **Keypad**.
3. Tap 911 and tap .

NOTE: As long as you're in an area covered by wireless service, the emergency call will go through .


* Availability of 9-1-1 location services (such as Enhanced 9-1-1) may depend on upgrades to the (a) wireless network and (b) 9-1-1 calling system that can only be installed by the local 9-1-1 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within your carrier's wireless coverage area or your roaming area. This approximation of the device's location or the transmittal of location information may be limited or unavailable because of factors including, but not limited to: emergency situations, transmission limits, network problems or limitations, interconnecting carrier problems, your device, buildings or tunnels, signal strength, and atmospheric or topographical conditions. When the device's 9-1-1 location services are active and functioning, the device's approximate location information is transmitted to the local 9-1-1 response agency or PSAP while the call is in progress. The device location approximation is intended solely to aid in dispatching emergency assistance or to limit the search area for emergency services personnel. Please see your wireless

carrier's Terms and Conditions and Privacy Policy for additional service restrictions and details.


Answer an Incoming Call

1. When a call arrives, slide  up to answer.
2. To end the call, tap .

Reject an Incoming Call

- When a call arrives, slide  down to reject it.



Reject a Call and Send a Text Message

1. When a call arrives, slide up from the bottom left of the screen.
2. Tap one of the messages to send it to the caller.
 - You can edit the Call Reject messages through the Call settings menu. From the phone app, tap **Menu**  > **Settings** > **Quick responses** and edit the Call Reject messages.

Call Settings



Your phone's Call Settings menu lets you configure your voicemail options and more.

Use the Call Settings Menu

1. From the Home Screen, tap **Phone** .
2. Tap **Menu**  > **Settings**
3. Configure your options.

Contacts


Add a Contact

1. From the Home Screen, swipe up and tap **Contacts** .
2. Tap  to add a contact.
3. Use the keyboard to enter as much information as you want.
4. When you have finished adding information, tap **SAVE**.

Edit a Contact


1. From the **Contact** screen, tap a contact to view its details.
2. Tap **Edit**.

Delete a Contact

1. From the **Contact** screen, tap a contact to view its details.
2. Tap **Menu**  > **Delete**.

Share a Contact

You can quickly share contacts using Bluetooth, Gmail, or messages.


1. From the **Contact** screen, tap a contact to view its details.
2. Tap a contact to display it, and then tap **Menu**  > **Share**.
3. In the **Share contact via** menu, select a method to send.

Messages




From the Home Screen, tap **Messages**.

Send a Text Message

Quickly compose and send text messages on your phone.

1. On the Messages screen, tap **Start chat**.
2. Fill in one or more recipients.
3. Tap the “Text message” box and then start composing your message
4. When done, tap **Send**  to send the text message.

Send a Multimedia Message (MMS)

1. On the Messages screen, tap **Start chat**.
2. Fill in one or more recipients.
3. Tap the “Text message” box, and then start composing your message.
4. Tap **Attach**  or **Camera** .
5. Tap **Send**  to send the MMS message.


Messages Settings

Tap on the top right corner of the Messages screen and tap **Messages Settings** to adjust your messages settings.


Apps and Entertainment

BoostMax™ Audio


BoostMax Audio increases loudness, bass, clarity, and voice presence to provide a greatly enhanced audio experience.




You can choose one of the following ways to access BoostMax Audio:

- From the Home Screen, tap **BoostMax Audio** .
- From the Home Screen, swipe up for the Apps list and tap BoostMax Audio. Or, swipe up for the Apps list and tap **Settings > Sound & vibration > BoostMax Audio** .

After the phone's initial setup, a BoostMax Audio popup window will appear on top of the Home Screen, you can tap **Try it now** to access the BoostMax Audio application. To quickly turn BoostMax Audio on or off,

swipe down on the status bar to access your Quick Settings Panel, then tap **BoostMax Audio** .

Camera





- **Flash:** Enable Flash, Auto Flash, or disable the Flash for the camera.
- **More Functions:** Choose additional camera settings, such as picture size, grid line.
- **Zoom slider:** Slide to zoom in or out.
- **Useful modes:** Switch between different camera modes.
- **Photos:** Enter the Photos and view photos.
- **Shutter:** Tap to take a photo.
- **Google Lens:** Search what you see through the camera.
- **Switch Cameras:** Switch between the back camera lens and the front-facing camera lens (for self-portraits, video chatting, etc.).

Switch Camera Modes




You can swipe left or right across the camera mode options to select a camera mode.

- **Night Mode:** Night mode allows you to take good-quality photos in low-light situations or at night.
- **Video:** Video mode allows you to record a video.
- **Photo:** Photo mode allows you to take a photo.
- **Beauty:** Beauty mode allows you to beautify your photo while shooting.
- **Portrait:** Portrait mode allows you to take a photo that keeps your subject sharp with a blurred background.
- **Pro Mode:** Pro mode allows you to customize camera settings including white balance, ISO, exposure, etc. to take professional photos.
- **Time Lapse:** Enable time-lapse photography for the camera.
- **Panorama:** Allows you to capture ultra-wide angle images.
- **Slow Motion:** allows you to take videos in slow motion.
- **AI Enhance Mode:** automatically identifies the current scene to optimize the photo effect, supporting 12 scenes such as Sunset, Gourmet, Blue Sky, Beach, etc.

Take a Photo

1. From the Home Screen, swipe up and tap **Camera** .
2. Aim the camera at your subject.
3. Tap  to take the photo.

Record a Video

1. From the Home Screen, swipe up and tap **Camera** .
2. Swipe to video mode and tap .
3. Tap  to stop recording.

Photo

Using the Photos application, you can view photos and watch videos that you've taken with your phone's camera, downloaded, or copied onto your storage card or phone memory.

View Photos and Videos

1. From the Home Screen, swipe up, and tap **Photos** .

2. Tap **Library**.
3. Tap an image to view the photo or video.

Calendar

Use Calendar to create and manage events, meetings, and appointments.

Add an Event to the Calendar

1. From the Home Screen, swipe up, and tap **Calendar**



2. Tap **Add**



3. Enter the details, tap **Save**.


Edit an Event

1. From the **Calendar** screen, tap a date and an event to view the details.
2. Tap **Edit** to edit the event and tap **Save** to save.

Delete an Event

1. From the **Calendar** screen, tap a date and an event to view the details.
2. Tap **Options** > **Delete** to delete the event.

Calendar Settings

1. From the **Calendar** screen, tap  > **Settings** > **General**.
2. Tap an option to adjust Calendar settings.

Clock

Your phone has a clock app that lets you set alarms, view time in time zones around the world, use a stopwatch, set a timer, and use your phone as a desk clock.

Set the Date and Time

Your phone automatically receives the current date and time from the wireless network. You can manually set the date by overriding the default setting.



1. From the Home Screen, swipe up and tap **Clock**
2. Tap **Menu** > **Settings** > **Change date & time**.



3. Tap **Set time automatically**, and then select **Off** in the pop-up window.
4. Set the date and time as desired.


Set Alarms

Set multiple alarms using your phone's Clock app.

1. From the Home Screen, swipe up and tap **Clock**.
2. Tap the **Alarm**  tab and then tap **Create alarm** .
3. Set the time and tap **OK**. Set the alarm options, including repeat pattern, alarm tone, and label.



World Clock

The world clock lets you keep track of the current time in multiple cities around the globe.

1. From the Clock app, tap **Clock** .
2. Tap **Add City**  and select a city.
3. Repeat to add multiple cities.




Timer

The timer provides a countdown timer for up to 99 hours, 99 minutes, and 99 seconds.


1. From the Clock app, tap **Timer** .
2. Use the keypad to set the length of the timer.
3. Tap **Start**  to begin the timer.

Stopwatch

The stopwatch lets you time events down to the hundredth of a second.

1. From the Clock app, tap **Stopwatch** .
2. Tap **Start**  to begin timing.
3. Tap **Stop**  to stop timing.

Bedtime

1. From the Clock app, tap Bedtime . Tap **Get Started** to start setting the bedtime.
2. Tap **Done** to finish setting.


Useful Settings

The following topics introduce your phone's basic settings menus.

Sound & Vibration

The sound settings menu lets you control your phone's audio, from ringtones and alerts to tap tones and notifications.


Access Sound Settings

1. From the Home Screen, swipe up and tap **Settings** .
2. Tap **Sound**.
3. Set your sound options.

Display

Use the phone's display settings menu to adjust items such as wallpaper, brightness level, screen timeout, and more.


Access Display Settings

1. From the Home Screen, swipe up, and tap **Settings** .
2. Tap **Display**.
3. Set your display options.

Accessibility

The accessibility settings menu lets you enable and manage accessibility-related applications.


Access Accessibility Settings

1. From the Home Screen, swipe up, and tap **Settings** .
2. Tap **Accessibility**.
3. Set available accessibility options.


Security & Privacy

The security settings menu lets you set encryption options and credential storage options, set your method for unlocking your phone, and customize lock screen options.


Screen Lock

1. From the Home Screen, swipe up and tap **Settings** .
2. Tap **Security & privacy > Screen lock**.

Fingerprint Unlock


1. From the Home Screen, swipe up, and tap **Settings** .
2. Tap **Security & privacy > Device Unlock > Face Unlock & Fingerprint Unlock > Fingerprint**.
3. Follow the on-screen instructions to enroll your fingerprint.

Face Unlock

1. From the Home Screen, swipe up, and tap **Settings** .
2. Tap **Security & privacy > Device Unlock > Face & Fingerprint Unlock > Face Unlock**.
3. Follow the on-screen instructions to enroll your face.

Extend Lock


Extend Lock keeps your phone unlocked while it's on you, at specific places that you trust, or near your connected devices.

1. From the Home Screen, swipe up, and tap **Settings**  **> Security & privacy**.
2. Tap **More security & privacy > Extend Unlock > On-body detection**.
3. Tap the slider to enable/disable on-body detection.

Safety & Emergency

The safety & emergency settings menu lets you add and manage your emergency information, set emergency location service, and more.


Access Safety & Emergency Settings

1. From the Home Screen, swipe up, and tap **Settings** .
2. Tap **Safety & emergency**.
3. Set your safety and emergency options.

Digital Well-being & Parental Controls

The digital well-being & parental controls menu lets you set app timers and parental controls.


Access Digital Well-being & parental controls Settings

1. From the Home Screen, swipe up, and tap **Settings** .
2. Tap **Digital Well-being & parental controls**.
3. Set available digital well-being & parental controls options.

Language

Your phone's language and input settings menu lets you select a language for the phone's menus and keyboards, select and configure keyboard settings, configure speech input settings, and set your phone's mouse/trackpad options.


Access Language Settings

1. From the Home Screen, swipe up, and tap **Settings** .
2. Tap **System > Language**
3. Set options.

Keyboard

The phone's Keyboard menu allows you to select the on-screen keyboard you need to use for your phone, select and configure keyboard settings, and set the phone's mouse/trackpad options.


Access Keyboard Settings

1. From the Home Screen, swipe up and tap **Settings** .
2. Tap **System > Keyboard**
3. Set options.

Date & Time

Use the Date & Time settings menu either to automatically use the network-provided date and time or manually set these values, as well as select time and date format options.

Access Date & Time Settings

1. From the Home Screen, swipe up, and tap **Settings** .
2. Tap **System > Date & time**.
3. Set available date and time options.


Update Your Phone

From time to time, software updates may become available for your phone. You can download and apply updates through the **Settings > System > System update** menu.

About Phone

The about phone menu lets you access important phone information, and view legal information.

Access About Phone Settings

1. From the Home Screen, swipe up, and tap **Settings** .
2. Tap **About phone**
3. Select or view available options.

Appendix

The following topics offer additional information for your phone, including, troubleshooting, FCC information, warranty information, and customer service contact information.

Troubleshooting

Check the problems and solutions below for troubleshooting solutions for common phone issues.

Problem: Phone freezes/operation is unstable.

Solution: Turn the phone off, then on again. If you're unable to turn the phone off, press and hold the Power/Lock key for a few seconds to force your device to restart. Data that was being edited is erased after your phone is powered on again.

Problem: Cannot use phone, mail, or Internet.

Solution 1: Check whether you are in an area where cellular signal is weak or not available ("out of service").

Solution 2: Power the phone off, then on again.

Solution 3: Is the phone in Airplane mode? To check that Airplane mode is canceled:

From the Home Screen, swipe up and tap  > **Network & internet** > **AirplaneMode Settings**

Solution 4: Is data communication disabled? To check that data communication is enabled:

From the Home Screen, swipe up and tap **Settings**  > **Network & internet** > **Mobile network** > **Choose the mobile carrier** > **Mobile data**

Problem: Battery level goes down quickly.

Solution: Are you in an area where cellular signal is weak? Have you been in an "out of service" area for a long period of time? Making calls or using data in areas where signal is weak or service is not available uses a lot of power and drains the battery quickly.

Problem: Cannot unlock screen.

Solution: Turn the phone off and then on again. If you are unable to turn the phone off, press and hold the Power/Lock key for a few seconds to force your device to restart. Data that was being edited is erased after your phone is powered off, then on again..

Problem: Sound pops momentarily during a call.


Solution: Are you changing location while calling? You may experience a popping sound when the cellular signal is weak and the phone switches to wireless coverage from a different cell sector or tower.

Problem: Call does not connect.

Solution 1: Was the number dialed using the area code? If not, try dialing using the full 10-digit number including the area code.

Solution 2: Are you in an area with poor wireless coverage? Try calling again from another area.

Solution 3: Activate Wi-Fi calling.

From the Home Screen, swipe up and tap **Settings**  > **Network & internet** > **Mobile network** > **choose the mobile carrier** > **Advanced** > **Wi-Fi Calling** > **Use Wi-Fi Calling**

FCC Notice and Cautions

This device and its accessories comply with Part 15 of FCC Rules. Operation

is subject to the following conditions:

- (1) This device and its accessories may not cause harmful interference.
- (2) This device and its accessories must accept any interference received, including interference that may cause undesired operation.

Part 15.21 Statement:

Changes or modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Part of Statement 15.105:

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If you experience interference with reception (e.g., television), determine if this equipment is causing the harmful interference by turning the equipment off and then back on to see if the interference is affected.

If necessary, try correcting the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for further assistance.

Consumer Information on SAR

This Model Phone Meets the Government's Requirements for Exposure to Radio Waves. Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government.

These FCC exposure limits are derived from the recommendations of two expert organizations, the National Council on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The exposure limit for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg).

The FCC exposure limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements. Tests for SAR are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value.

Because the phone is designed to operate at multiple power levels to use only the power required to reach the network, generally, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure.

The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. This device was tested for typical body-worn operations with the back of the phone kept 0.39 inches (1.0 cm) between the user's body and the back of the phone.

To comply with FCC RF exposure requirements, a minimum separation distance of 0.39 inches (1.0 cm) must be maintained between the user's body and the back of the phone. Third-party belt clips, holsters, and similar accessories containing metallic components should not be used.

Body-worn accessories that cannot maintain 0.39 inches (1.0 cm) separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines.

The highest SAR value for this model phone when tested for use at the ear is 1.19 W/kg and when worn on the body, as described in this user's manual, is 1.19 W/kg. While there may be differences between SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/ea/fccid/> after searching on FCC ID: 2A28USN339D.

To find information that pertains to a particular model phone, this site uses the phone FCC ID number which is usually printed somewhere on the case of the phone. Once you have the FCC ID number for your phone, follow the instructions on the website and it should provide values for typical or maximum SAR for that phone.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at <http://www.ctia.org/>. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaging over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

FCC Hearing-Aid Compatibility (HAC) Regulations for Wireless Devices

This device has been tested and rated for use with hearing aids, with some of the wireless technologies that it uses. However, there may be newer wireless technologies used in the device that have not been tested yet for use with hearing aids.

It is important to try the different features on your device thoroughly and in different locations whilst using a hearing aid or cochlear implant to determine if there is any interfering noise.

This device was tested for compliance to the ANSI C63.19-2019 standard for HAC. Devices tested to this version of the standard, unlike previous versions, do not receive a HAC performance rating level; they are either HAC-compliant or not. In addition, in this version of the standard, the conversational gain of the device is tested, both with and without hearing aids.

The conversational gain force lowest conversational gain is 9.98dB with a hearing aid and force lowest conversational gain is 15.40dB without a hearing aid.

Celero5G SC Limited Warranty

What Does This Limited Warranty Cover?

Coosea USA Technologies Inc. (“Coosea”) as the Manufacturer warrants your Celero5G SC device (“Product”) against defects in materials and workmanship if purchased from Boost Mobile, Boost Infinite or Boost Mobile/Infinite authorized resellers or distributors and extends only to the original user of such Products under ordinary consumer use in accordance with the documentation and/or user manuals provided or made available with the Product.

How Long Does the Coverage Last?

If your Product was purchased from an authorized Boost Mobile/Boost Infinite reseller or distributor, or directly from Boost Mobile/Boost Infinite, your Product is warranted to be free of defects in materials and workmanship for two (2) years from the original date of purchase (the “Warranty Period”). Products repaired or replaced under this Limited Warranty are covered for the balance of the original Warranty Period. Any upgrade to the original product will be covered only for the duration of the Warranty Period.

What will Coosea Do?

In the event your Product is defective and (i) the defect is covered by this warranty; and (ii) the defect arises during the Warranty Period; and (iii) you follow the instructions for returning the defective Product, then Coosea will, at its option and to the extent permitted by law, repair or replace your defective Product with a new or refurbished Product that is functionally equivalent to the Product being replaced. This limited warranty will continue to apply to any replacement Product that Coosea provides, but only for the remainder of the original Warranty Period applicable to you.

How Do You Get Warranty Service?

For specific instructions about how to obtain warranty service for your Product during the Warranty Period, please contact the Coosea customer service department at (866) 235-5988 (for warranty purpose only). Proof of purchase may be required to verify eligibility. You may be instructed to download or otherwise obtain and accept software updates. You are responsible for any applicable carrier service fees incurred while obtaining the required downloads. Complying with the warranty process, repair instructions, and accepting such software updates is required in order to receive additional warranty support.

If the software update does not fix the problem, then you will need to deliver your defective Product in either its original packaging or in equally protective packaging to the address specified by the Coosea customer service department, at your own expense. Coosea will pay for shipping of the replacement Product to your location if all instructions regarding warranty services are followed; however, since Coosea will not be able to determine whether your Product is defective or otherwise covered by this Limited Warranty until inspection, you must agree to be charged an out of warranty fee if such inspection reveals your Product is not covered by this Limited Warranty.

When a Manufacturer's product or part is replaced, any replacement item becomes the customer's property and the replaced or refunded item becomes the Manufacturer's property.

Before you deliver your defective Product for warranty service, it is your responsibility to back up any data, software or other information or materials you may have stored, preserved or loaded, remove all personal information, and disable all security features on such Product. COOSEA IS NOT RESPONSIBLE FOR ANY DAMAGE TO, OR THE LOSS OF ANY DATA, SOFTWARE OR OTHER INFORMATION OR MATERIALS THAT YOU MAY HAVE STORED, PRESERVED OR LOADED ON YOUR PRODUCT. YOU ARE SOLELY RESPONSIBLE FOR BACKING UP, DOWNLOADING, AND REINSTALLING ANY AND ALL DATA, SOFTWARE, OR OTHER INFORMATION OR MATERIALS CONTAINED ON YOUR PRODUCT SUBMITTED FOR WARRANTY SERVICE.

What Does This Limited Warranty Not Cover?

You may only exercise this Limited Warranty from the United States. Coosea will not send repaired or replacement products to addresses outside the United States. If your Product is not covered by this Limited Warranty, Coosea may offer to provide out-of-warranty service to you at Coosea's then-current rates, which includes the cost to ship a refurbished unit to you that has the same or similar features. Do not open the Product or attempt to repair the Product yourself; such conduct may cause damage that is not covered by this Limited Warranty. This Limited Warranty does not cover the following:

- (a) defects or damage resulting from external causes, accident, misuse, abnormal use, abnormal conditions, improper storage, exposure to liquid, moisture, or dampness (including contact with water, rain, or extreme humidity or perspiration), sand or dirt, neglect, or unusual physical, electrical or electromechanical stress;
- (b) scratches, dents, or other cosmetic damage, unless caused by Coosea;
- (c) ordinary wear and tear, including but not limited to diminishment of consumable parts such as batteries or protective coatings that are designed to diminish over time, unless such failure have occurred due to a defect in materials or workmanship;
- (d) defects or damage resulting from the use of Product in conjunction or connection with accessories, products, or ancillary/peripheral equipment not furnished or approved by Coosea;
- (e) defects or damage resulting from improper testing, operation, maintenance, installation, service, modification, or adjustment not furnished or performed by Coosea or its authorized service centers, including but not limited to installation of unauthorized software and unauthorized root access, both of which shall void this Limited Warranty;

- (f) defects or damage resulting from viruses or other software problems introduced into the Product;
- (g) Product purchased outside the United States;
- (h) use of the Product for commercial rental purposes;
- (i) shipping damage if you fail to pack and ship defective Product in the manner prescribed by Coosea or its authorized service centers; or
- (j) Product that has been altered in any manner so as to prevent Coosea from determining whether such Product is covered under the terms of this Limited Warranty is excluded from coverage. The forgoing shall include but not be limited to (i) serial numbers, date tags or other manufacturer coding that has been removed, altered or obliterated; (ii) mismatched or duplicated serial numbers; or (iii) broken seals or other evidence of tampering.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES AND REMEDIES, AND COOSEA SPECIFICALLY DISCLAIMS ALL STATUTORY AND IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND AGAINST HIDDEN OR LATENT DEFECTS.

IN THE EVENT COOSEA CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES OR REMEDIES, THEN TO THE EXTENT PERMITTED BY LAW, ANY AND ALL SUCH WARRANTIES AND REMEDIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY AND TO THE REPLACEMENT OF YOUR PRODUCT. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG A STATUTORY OR IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, COOSEA IS NOT RESPONSIBLE FOR ANY DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL OR OTHER INDIRECT DAMAGES ARISING OUT OF, RELATING TO OR INCURRED IN CONNECTION WITH USE OF THE PRODUCT, WHETHER FOR BREACH OF WARRANTY OR BROUGHT UNDER ANY OTHER LEGAL THEORY. THIS LIMITATION AND WAIVER ALSO APPLIES TO ANY CLAIMS YOU MAY BRING AGAINST ANY OTHER PARTY TO THE EXTENT THAT COOSEA OR ANY OF ITS AFFILIATES, PARENT COMPANIES OR SUBSIDIARIES WOULD BE REQUIRED TO INDEMNIFY THAT PARTY FOR SUCH CLAIM. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

UNDER NO CIRCUMSTANCES SHALL COOSEA'S LIABILITY, IF ANY, EXCEED THE PURCHASE PRICE PAID FOR YOUR PRODUCT.

COOSEA RESERVES THE RIGHT TO REFUSE TO HONOR THIS LIMITED WARRANTY IF IT DETERMINES THAT ANY OF THE EXCEPTIONS DESCRIBED ABOVE HAVE CAUSED YOUR PRODUCT NOT TO HAVE PERFORMED PROPERLY.

THIS LIMITED WARRANTY SHALL BE VOID IF ANY FACTORY-APPLIED IDENTIFICATION MARK, INCLUDING BUT NOT LIMITED TO THE SERIAL NUMBER, HAS BEEN ALTERED OR REMOVED. THIS LIMITED WARRANTY SHALL ALSO BE VOID IF THE PRODUCT HAS BEEN OPENED BY AN UNAUTHORIZED PERSON.

THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE IN THE UNITED STATES. TO THE EXTENT THAT THIS LIMITED WARRANTY IS INCONSISTENT WITH LOCAL LAW, THIS LIMITED WARRANTY SHALL BE DEEMED MODIFIED TO BE CONSISTENT WITH SUCH LOCAL LAW.

No Boost Mobile reseller, service center, agent, or employee is authorized to make any modification, extension, or addition to this Limited Warranty. This Limited Warranty is governed by and construed under the laws of the state in which you purchased this Product. Coosea or its successor in title is the warrantor under this Limited Warranty.

Warranty Contact Information

For warranty service only, please email cooseaus_care@cooseaus.com or contact our Toll- Free line at (866)235-5988 (only for warranty).

Copyright Information

Celero and other words, slogans, designs and devices are trademarks or registered trademarks of DISH Wireless L.L.C. Copyright © 2024 DISH Wireless L.L.C. Google, Android, Google Play, Google Drive and other marks are trademarks of Google LLC. Other company and product names mentioned herein may be trademarks of their respective owners. Screen and product images are simulated; they may differ from the actual product and are subject to change. Coosea USA Technologies Inc. reserves the right to add, modify or delete, any of the contents herein or withdraw this document at any time without prior notice or any reasons thereof.